

MAX LEAN FOOT CONTROLS

INSTALLATION GUIDE

DISCLAIMER: Kraus Motor Co. recommends that you defer to a certified mechanic or technician on any installation when possible. Refer to your OEM service manual for step-by-step procedures, required tools and specifications to make sure all pieces and parts are properly installed. Kraus Motor Co. is not responsible for improper installation of any OEM or Kraus component/kit. After completing installation, go for a slow, careful test ride. Afterwards, double-check all pieces, parts and systems. Improper installation may result in severe injury or death.

FLOORBOARDS

FITMENT NOTE:

2024+ CVO Road Glide ST Models require HD ON: 47200302A (x2) Floorboard Mounts

2023+ CVO Models require HD PN: 50674-05 (x4) Shoulder Bolt

BEGIN INSTALLATION

- Remove the OEM Floorboards from the original mounting brackets
- You will reuse the original shoulder bolt, but you **WILL NOT** reuse the OEM flange nut
- Install Kraus Floorboard mount in preferred location, then torque to **70-80 in-lbs (Fig. 1)**
- Add loctite and insert set screw to preferred pitch height (**Fig. 2**)
- Install the Kraus Floorboard on the OEM brackets, then torque shoulder bolts to **60-80 in-lbs**

FLOORBOARD ADJUSTMENTS

The 5 bolt holes on each mount allow you to adjust the floorboards outwards or inwards to the bike (**See Fig. 1**)

- Locate a comfortable position before continuing the installation process

The set screw is used to adjust the pitch of the floorboards. The further out the set screw is, the higher the pitch will be (**See Fig. 2**)

- The set screw will need to be adjusted and set **BEFORE** the floorboard can be installed on the HD mounts

