KRAUS ISOLATED RISER LEG REPLACEMENT INSTALLATION

INSTALLATION GUIDE:

- 1. Loosen but do not remove two $\frac{1}{2}$ x 13 bolts on the bottom of the triple tree.
- 2. Remove one bolt and swing riser assembly to one side of the motorcycle
- 3. Use heat to loosen Loctite in the upper portion of the riser leg.
- 4. Use impact gun and 5/8 Allen to loosen riser leg.
- 5. Apply blue Loctite 243 to new riser leg inner threads
- 6. Install new riser leg and torque to 55 ftlbs
- 7. Repeat process for opposite side
- 8. Reinstall two $\frac{1}{2}$ -13 x 3 bolts with blue Loctite to riser leg and torque to 55 ft lbs.

TOOLS NEEDED:

- 5/8 allen 3/8 or 1/2 drive
- 3/4 socket 3/8 drive
- Impact gun air or electric
- Heat source map gas, heat gun

